

SG-4888

UNIVERSAL A/C REMOTE CONTROL

Brand Table

AIRWELL	HAIER	SAIJO DENKI
ALPIN	HISENSE	SHARP SAMPO
AUCMA	HITACHI	SAMSUNG
AUX	HUABAO	SANYO
BOERKA	HUALING	SHINCO
CARRIER	HYUNDAI	SWAN
CHANGHONG	JOHNSON	TADIRAN
CHIGO	KELON	TATUNG
CHUNLAN	LG	TCL
DAEWOO	MACQUAY	TOSHIBA
DAIKIN	MIDEA	TRANE
ELECTROLUX	mitsubishi	WHIRLPOOL
FRESTECH	PANASONIC NATIONAL	WINIA
FUJITSU	PHILCO	YINYAN
GALANZ	ROWA	YORK
GREE		OTHER BRAND



CE

MADE IN CHINA
NO. K-E-00181

 SIGMA®

SG-4888

Brand on LCD

Universal
A/C
Remote
Control
2000 IN 1

Display A/C brands
directly on LCD

Big screen LCD

Conversion between
C&F degree

Unique function of
"Intelligent cool" and
"Intelligent heat"

Room temperature



CONTROL 99.99 PERCENT OF A/C'S IN THE WORLD

SG-4888

One for all brands Universal air conditioner remote controller



Product Description

SG-4888 is the latest product, it is a brand universal remote with patent technologies which is invented by our engineers: Place batteries, it can work for almost all brands in the world without setting, It is the best choice for you to replace the remote.

Thanks you for choosing our remote, it is honored that we can provide conveniences for your life.

Please read this manual carefully before using, which will be a great help for you to use the remote control.

Setting

Select brands directly

1. Suitable for those brands listed in the "table list".
2. Press and hold "Brand" key, the symbol "Brand" on LCD blinks.
3. Enter brand letters in order, then can control your Air-conditioner.
4. There are 3-4 letters on a button, please press the key quickly once, twice, three or four times according to the letter's sequence.
E.g: button "ABC" you need "C" then press three times as soon as possible.
5. If remote does not work well, please use "Auto Searching" as below:
 - ① Press and hold "OK" key.
 - ② Release "OK" key as quickly as air conditioner sends "BUZZER" sound.
 - ③ Check all other functions whether can work or not, if it does not work; repeat above steps until it can use for your equipment.

Warm Tips:

The remote can identify the brand automatically. E.g: brand "GALANZ" you only should press "G" then all the words of "GALANZ" will appear and "GREE" only should press "G" and "R" then "GREE" will appear.

Using of "intelligent Cooling" "intelligent heating"

In the summer, press the "intelligent Cooling" only, the air conditioner will be cooled immediately.

In the winter, press the "intelligent heating" key only, the air conditioner will be heated immediately. In both status, the air conditioner will let the heating and cooling in a comfortable temperature automatically, and the fan and swing are all automatic. At the same time, it also can adjust the temperature by "Temp.+" "Temp.-" keys as your requires. These two intelligent keys are very good for the children and the old.

Clock set up

1. Press the "CLOCK" button, it is blinking.
2. Press the "TIME+ or -", setting to the current time.
3. Press the "CLOCK" button again, stop blinking, the time setting is complete.
(If you did not press the "CLOCK" button, it can be setting automatically after 8 seconds) time and clock signal. Now setting is complete.

Timer on

1. Press the "TMR ON" key, the time on LCD flashes.
2. Press "TIME+/-" key, adjust the time when you want to make the air conditioner turn on automatically.
3. Time on LCD will stop flash after 15 seconds. Setting is complete.

Timer off

1. Press the "TMR OFF" key, the time on LCD flashes.
2. Press "TIME+/-" key, adjust the time when you want to make the air conditioner turn off automatically.
3. Time on LCD will stop flash after 15 seconds. Setting is complete.

NOTE

1. If press the "TIMER ON" or "TIMER OFF" key twice, timer is cancel.
2. After timer setting is finished, you should make the remote control's emit directs to your air conditioner's receiving location in available distance. If not, it can not work.
3. If you want to watch the time of timer, you should press the "TIMER ON" or "TIMER OFF" key, the LCD will display the time of timer and after 5 seconds it will display current time.

Conversions between Celsius and Fahrenheit degree

Press the "C/F" key can convert the display between Fahrenheit and Celsius degree.

Sleep function

In the summer, press the "SLEEP" key while it is in cool mode, the temperature will be raised 1°C per hour in the first 2 hours and will be shut off by itself after 8 hours. In the winter, press the "SLEEP" key while it is in heat mode, the temperature will be fall 1°C per hour in the first 2 hours and will be shut off by itself after 8 hours. After setting sleep function, please let remote aim at the receiver of your air conditioner in the effective distance, otherwise the function of "SLEEP" is null.

Technical Parameters

Controllable distance : Large than 8 meters
Power supply voltage: DC 3 V
Battery model: Battery AAA(UM-4, R03)×2
Dimension: L165mm×W55mm×D25mm
Weight: Approx100g(excl.the batteries)